

WeekNr

%WeekNr function

Function	The function returns the serial number of the week of a given absolute time.				
Declaration	<pre>INT %WeekNr(TIME in Time, TEXT in timeZone := %GetCurrentTimeZone())</pre>				
Parameters	<table><tr><td>T i m e</td><td>Function argument.</td></tr><tr><td>t i m e Z o n e</td><td>Name of the time zone used for conversion to local time (e.g. "Europe/London") or definition of fixed offset from UTC using format "(+/-)hh[:mi[:ss]]", where <i>hh</i> defines a number of hours, <i>mi</i> defines a number of minutes, and <i>ss</i> defines a number of seconds. Sign as well as a number of hours are mandatory parts of offset definition, number of minutes and seconds are optional and default to 0 (e.g. "+02:30" defines offset of 2 hours and 30 minutes from UTC). The empty text has the same meaning as function %GetCurrentTimeZone. Note: For historical reasons, an integer parameter is also accepted. Its interpretation is as follows: 0 - zone "Europe/London", 3600 - zone "Europe/Bratislava", 7200 - zone "Europe/Kiev", 21600 - zone "Asia/Almaty". Usage of integer parameter is deprecated and generates warning into log file!</td></tr></table>	T i m e	Function argument.	t i m e Z o n e	Name of the time zone used for conversion to local time (e.g. "Europe/London") or definition of fixed offset from UTC using format "(+/-)hh[:mi[:ss]]", where <i>hh</i> defines a number of hours, <i>mi</i> defines a number of minutes, and <i>ss</i> defines a number of seconds. Sign as well as a number of hours are mandatory parts of offset definition, number of minutes and seconds are optional and default to 0 (e.g. "+02:30" defines offset of 2 hours and 30 minutes from UTC). The empty text has the same meaning as function %GetCurrentTimeZone . Note: For historical reasons, an integer parameter is also accepted. Its interpretation is as follows: 0 - zone "Europe/London", 3600 - zone "Europe/Bratislava", 7200 - zone "Europe/Kiev", 21600 - zone "Asia/Almaty". Usage of integer parameter is deprecated and generates warning into log file!
T i m e	Function argument.				
t i m e Z o n e	Name of the time zone used for conversion to local time (e.g. "Europe/London") or definition of fixed offset from UTC using format "(+/-)hh[:mi[:ss]]", where <i>hh</i> defines a number of hours, <i>mi</i> defines a number of minutes, and <i>ss</i> defines a number of seconds. Sign as well as a number of hours are mandatory parts of offset definition, number of minutes and seconds are optional and default to 0 (e.g. "+02:30" defines offset of 2 hours and 30 minutes from UTC). The empty text has the same meaning as function %GetCurrentTimeZone . Note: For historical reasons, an integer parameter is also accepted. Its interpretation is as follows: 0 - zone "Europe/London", 3600 - zone "Europe/Bratislava", 7200 - zone "Europe/Kiev", 21600 - zone "Asia/Almaty". Usage of integer parameter is deprecated and generates warning into log file!				
Example	<pre>%WeekNr(SysTime) ; result is the serial number of the current week</pre>				
Note	<p>For the date of January 1st, the function returns the value of 1.</p> <p>For the last week of a year and the first week of the next year, the function returns different values although the weeks could be the same in the calendar.</p> <p>To avoid this difference, we recommend you to use the function %WeekOfYear.</p>				



Related pages:

- [Implemented functions](#)
- [Function arguments - types](#)