

GetItemStTextRef

%GetItemStTextRef function

Function

The function detects HBJ of object Status text type which is attached to entered column of the [structure](#) or [structured variable](#).

Declaration

```
INT %GetItemStTextRef(  
    HBJ in objRef,  
    INT in col  
)
```

Parameters

objRef	Expression of HBJ type - reference to object of Structured variable type or Structure definition .
col	Column index.

Description

The function gets back an invalid value:

- if **objRef** is the reference to unknown object, or the object is not Structured variable type or Structure definition
- if the value of parameter **col** is out of range which is given by columns number of relevant object.

If function gets back the value 0, the object Status text is not assigned to specific column.

Example

```
RECORD (SD.Struct)_rec  
  
INT _stTextHBJ  
_stTextHBJ := %GetItemStTextRef(SD.Struct\HBJ, 1)  
_stTextHBJ := %GetItemStTextRef(SV.Struct\HBJ, 3)  
_stTextHBJ := %GetItemStTextRef(_rec\HBJ, 2)
```



Related pages:

[ESL extended functions](#)
[Function arguments - types](#)
[%GetStTextBase function](#)
[%GetStTextRange function](#)
[%GetStTextStep function](#)
[%To_String function](#)