HI_GetColumnMetadata

%HI_GetColumnMetadata, %HI_SetColumnMetadata functions

Function

%HI_GetColumnMetadata function gets back a text value of metadata (according to defined key) that are assigned to the column of graphic object Browser.
%HI_SetColumnMetadata function sets a new text value of metadata (according to defined key) that are assigned to the column of graphic object Browser.

Declaration

```
TEXT %HI_GetColumnMetadata(
  INT in _refId,
  INT in _index,
  TEXT in _key
 )

 BOOL  %HI_SetColumnMetadata(
  INT in _refId,
  INT in _index,
  TEXT in _key,
  TEXT in _value,
  BOOL in _bOverWrite
 )
```

Parameters

_refId	Reference to graphic object (reference variable).
_index	Consecutive number of column.
_key	Key which specified metadata.
_value	New value of metadata.
_bOverWrite	TRUE - either metadata are inserted (if they do not exist) or the value of existing metadata is updated. FALSE - either metadata are inserted (if metadata do not exist) or the existing value of metadata is kept.

Description

%HI_GetColumnMetadata function gets back the text value of metadata (according to the defined key) which is assigned to column of *Browser* graphic object.
%HI_SetColumnMetadata function sets new metadata (according to defined key) to column of *Browser* g raphic object.

Note 1

Configuration of metadata for column of graphic object Browser.

%HI_SetColumnMetadata function applies the change of metadata only on the running instance of picture.

Note 2

These functions are available also in %HIX_ version.

Related pages:

Graphic object manipulation functions
Function arguments - types