HI_SetGraphRowNr

%HI_SetGraphRowNr function

Old name

%HI_SetDiatRowNr

Function

The function **%HI_SetGraphRowNr** sets the number (index) of the displayed row of structured object in active objects of the graph which is connected to the displayer of Graph type (Control function).

Declaration

```
%HI_SetGraphRowNr(
   INT in refId,
   INT in rowIdxInt
 )
```

Parameters

refId	Reference to graphic object (reference variable).
rowIdxInt	Number of the structured object row.

Related pages:

Graphic object manipulation functions
Function arguments - types