# HI_InsertTextEF

## %HI_InsertTextEF function

**Function**

The function inserts a text into current position of the windows control Text entry field (control function).

**Declaration**

```
%HI_InsertTextEF(
   INT in refEntryField,
   TEXT in text
 )
```

**Parameters**

| | |
|---|---|
| **refEntryField** | Reference to *Entry field* (reference variable). |
| **text** | Text to be inserted. |

**Description**

If several characters are selected in the windows control the inserted text will replace them.
Example:

**Example**

```
%HI_InsertTextEF(_refEntryField,"will be inserted")
```

**Related pages:**

Graphic object manipulation functions
Function arguments - types