InitStation

Declaration

```
unsigned int _stdcall InitStation(struct StationPar * St)
```

Parameters

St	Pointer to StationPar structure.

Description

The function InitStation (_InitStation@4 in the Stdcall calling sequence) is optional. A pointer to a *StationPar* structure with a definition of the station parameters is the parameter of the function. The function is called at starting of the process D2000 KOM and later after a change of the station parameters in the process D2000 CNF.

Return code

Code	Description
RQ_OK	Request executed OK.
RQ_ERR	An error occurred (device doesn't communicate, out of order, or any error).
RQ_IGNORED	The function was ignored and the station status is not changed.

Related pages:

D2000 KomAPI - interface functions