HI_GetGraphAxis

%HI_GetGraphAxis, %HI_SetGraphAxis functions

Function

The function **%HI_SetGraphAxis** sets the number of axis to be displayed in displayer of Graph or XY Graph types (control function).

The function **%HI_GetGraphAxis** returns the number of an axis displayed in displayer of Graph or XY Graph types.

Declaration

```
%HI_SetGraphAxis(
   INT in refId,
   INT in axis,
   INT in nr
 )


 INT %HI_GetGraphAxis(
   INT in refId,
   INT in axis
 )
```

Parameters

refId	Reference to displayer (reference variable).
axis	Axis in graph. Possible values: • *1* - left axis • *2* - right axis
nr	Axis serial number. Value of 0 - axis not displayed.

Description

The function **%HI_SetGraphAxis** sets the axis defined by the parameter *nr* as right or left one (according the parameter *axis*).

The function **%HI_GetGraphAxis** retrieves the number of right or left axis.

Related pages:

Graphic object manipulation functions
Function arguments - types