HI_SetGraphLineStat

%HI_SetGraphLineStat function

Function

The function sets the statistic function displayed in the **Universal** column for given object in the graph table (control function).

Declaration

```
%HI_SetGraphLineStat(
   INT in refId,
   INT in lineNr,
   INT in statFnct
 )
```

Parameters

refId	Reference (reference variable) to displayer of Graph type.
lineNr	Serial number of graphic flow.
statFnct	Type of statistic function. Possible values: • *1* - minimum • *2* - maximum • *3* - last value • *4* - sum • *5* - average **Note:** Value other than abovementioned disables the statistics, i.e. the **Universal** column will not show any value.

Description

The function sets the statistic function specified by the parameter *statFnct* for object *lineNr*. Result if of the statistic function is to be shown in the table of displayer of Graph type (parameter *refId*) - the **Universal** column - for given object.

Note

More information - the parameter Table columns in the configuration of graphs.

Related pages:

Graphic object manipulation functions
Function arguments - types