StationsApplyBack

Declaration

```
void _stdcall StationsApplyBack(StationPar *St, void *AplPar)
```

Parameters

St	pointer to StationPar structure
AplPar	void pointer (it is defined as one of the parameters of the function StationsApply)

Description

The function **StationsApplyBack** (_StationsApplyBack@8 in the Stdcall calling convention) is optional. It is a response to calling the call-back functions StationsApply. The function is called specially for all stations of the line defined in the parameter *LnId* of the function StationsApply.

Related pages:

D2000 KomAPI - interface functions