HI_SetDraggable

%HI_SetDraggable function

Function

Function **%HI_SetDraggable** enable / disable a possibility to move particular object in picture.

Declaration

```
%HI_SetDraggable(
   INT in refId,
   BOOL in _onoff,
   INT in _moveType,
   BOOL in _visible
 )
```

Parameters

refId	Reference to displayer (reference variable).
_onoff	Enable / disable the possibility to move object.
_moveType	If the parameter is: • 0 - it allows moving only on X-axis • 1 - it allows moving only on Y-axis • 2 - it allows moving on X-axis and Y-axis • other number - the function will be ignored
_visible	Enable / disable a visibility of object (@True = the object is visible, @False = the object is invisible).

Example

```
%HI_SetDraggable(_LINE, @TRUE, 2, @TRUE)
```

Note

The function is not allowed for ActiveX controls, Displayers, Windows controls, SWTShell and JavaSwing.

Related pages:

Graphic object manipulation functions
Function arguments - types
%HI_SetDragRange function
ENTRY OnDragMove