

Control Process Alarms by means of the Object Control Window (Work with D2000 HI)

Controlling the process alarm by means of the object control window

!!! OLD CONTROL WINDOWS !!!

Process alarms may be controlled using the control window of the object, for which particular alarm is defined. An example of such control window is shown in the following figure.

1	Open the process alarm control window.
2	Acknowledge the process alarm.

The button to control process alarm (1) contains information on status of the process alarm. Clicking the button will open the following dialog box.

Acknowledge	Acknowledge the process alarm
Block	Block the process alarm.
Unblock	Unblock the blocked process alarm.
Close	Close the dialog box.