

# License file

An integral part of Runtime license (Runtime HW key or Software key) and development license (OEM HW key) is so-called "license file" containing a D2000 system license. It is a text file containing the license number, user and date when the license was issued (only for information purpose) and coded license range.

```
; LIC.NUMBER = 1234567890
; LIC.USER = SuperTech s.r.o. Bratislava
; LIC.DATE = 27.08.2012 13:00
[LICENCE]
21FD1D4D-18F98A11-71FC8326-E10AB606-2F4BB18A-695EC340-D201A921-F72D189C-2196425E-808AFF07-
6094B0E0-4FB5B897-3D1AF1F0-0242254E-137B399F-DB65A494-4DF3
```

The name of this file is **LicenceRun.code** for Runtime licenses (together with Runtime HW key) and **LicenceDev.code** for development licenses (together with a OEM HW key). The files must be located directly in the [installation directory](#) (one of two directories you set when installing the D2000 system). If you are not sure which directory is the installation directory, it is the value of the registry key contents "HKEY\_LOCAL\_MACHINE\SOFTWARE\Ipesoft\D2000VXX\InstallDir" of the computer. The string D2000VXX must be replaced by your version of the D2000 System.

Example of the list of the directory contents (C:\D2000\D2000.EXE is, in this case, the product files directory):

```
Directory of C:\D2000\D2000.EXE

04.09.2012  14:55    <DIR>          .
04.09.2012  14:55    <DIR>          ..
05.08.2012  08:28    <DIR>          bin
05.08.2012  08:27    <DIR>          Help
05.08.2012  08:27    <DIR>          INST_ODBC
05.08.2012  08:28    <DIR>          Msg
05.08.2012  08:25    <DIR>          ProtDll
05.08.2012  08:28    <DIR>          ResDll
05.08.2012  08:26    <DIR>          Templates
27.07.2011  11:27    <DIR>          Utils
28.08.2012  10:00                255 LicenceDev.code
27.08.2012  13:00                255 LicenceDev.code
15.05.2012  11:21                258 LicenceRun.code
02.08.2012  20:29                60 Version
```

All license keys of OEM type, issued for one customer, use the identical license (file "LicenceDev.code").

Correct location of the license file is provided by the D2000 System installation directly from the installation DVD issued by the IPESOPT company for particular Runtime application. If you install your D2000 System from so-called OEM DVD, you must copy the license file manually (e.g. from USB flash disc, e-mail).

The useful feature is that you can change the license range - license file, while D2000 System is running (without need to stop it). After changing the license file, you have to send the tell command [REFRESH\\_LICENCE](#) on D2000 Server.

If [hardware key](#) has been plugged in properly or there are the correct conditions for application of [software key](#), the D2000 system together with the license file are installed, you can view the license options using the [D2000 Application Manager](#) before running the process [D2000 Server](#).



## Related pages:

[Licensing the D2000 products](#)