

# Functions for Calculated Historical Values

## Functions for calculated historical values

The following functions can be only used in the [statement](#) that determines the value of object of [Historical value type](#).

The functions can be defined either directly by typing them or selecting from the list of functions. The [list of functions](#) is opened after clicking the button **Functions** in the configuration dialog box (the tab [Statement](#)) of objects of *Historical value type*.

- %ARC\_Derivation
- %ARC\_GetValue
- %ARC\_Nowrite
- %ARC\_Unwrite

