

Informané dialógové okno poa archívnych hodnôt (D2000 /Práca operátora s procesom D2000 HI)

Informané dialógové okno objektu typu *Pole hodnôt* pozostáva z 2 záložiek:

[Stav a ovládanie objektu](#)
[Informácie o objekte](#)

Stav a ovládanie objektu

The screenshot shows the 'X.ArcPole' dialog window. It features a title bar with the window name and standard OS controls. Below the title bar is a toolbar with icons for edit, zoom, save, and print. The main content area displays the current value 'Aktuálna hodnota: 23,56 kPa' and a timestamp '16.03.2021 15:34:00,004'. A table below shows a history of values, all of which are 61.2475527171936 kPa. A 'Prepnúť' button is visible next to the table. A yellow box highlights the table, and a yellow circle highlights the '6' in the third row. Numbered callouts 1-6 point to specific UI elements: 1 points to the window title, 2 to the toolbar, 3 to the current value, 4 to the timestamp, 5 to the 'Invalid' button, and 6 to the value in the table.

1

2

3

4

5

6

Invalid

Manuálne





61.2475527171936 kPa

Prepnúť

Index	Čas zmeny hodnoty	Hodnota
1	16.03.2021 15:34:00,000	61.2475527171936
2	16.03.2021 15:34:01,000	61.2475527171936
3	16.03.2021 15:34:02,000	61.2475527171936
4	16.03.2021 15:34:03,000	61.2475527171936
5	16.03.2021 15:34:04,000	61.2475527171936

> Informácie o objekte

1	Názov objektu.
2	Popis objektu.
3	Aktuálna hodnota a technické jednotky objektu.
4	as posledného priradenia hodnoty objektu.

5	Flagy (príznaky) hodnoty objektu. Zobrazené sú len mená tých flagov, ktorých hodnota je TRUE.
6	Zobrazenie prvkov poa archívnych hodnôt.
	Editácia objektu. Je možná iba ak je bežiaci proces CNF.
	Otvorenie monitorovania
	Zaradenie ovládaného objektu na aktuálnu stránku otvoreného Browsera . Ak Browser nie je otvorený, po stlačení tohto tlačidla sa otvorí a ovládaný objekt sa zaradí na jeho prvú stránku.
	Kopírovanie mena objektu do schránky (clipboardu).