

HI_SetBmp

%HI_SetBmp function

Function

Function changes bitmap in graphic object Bitmap.

Declaration

```
%HI_SetBmp(  
    INT in refId,  
    HBJ in bmp,  
    BOOL in bOriginalSize,  
    BOOL in byCenter,  
    [, BOOL in bProportional]  
)
```

Parameters

refId	Reference to graphic object (reference variable).
bmp	Bitmap.
bOriginal Size	@TRUE - by its size @FALSE - by the size in HI
byCenter	@TRUE - by the centre size in HI @FALSE - by the location (upper left point)
bProportional	@TRUE - it draws a picture and keeps its aspect ratio in the area of active bitmap @FALSE - it draws a picture and adjust it to the defined area of active bitmap. @FALSE is used if the parameter is not defined.

Description

Function changes bitmap in graphic object Bitmap from script.

Example

```
%HI_SetBmp(_bmp, otvor.bmp\HBJ, @TRUE, @FALSE, @TRUE)
```



Related pages:

[Graphic object manipulation functions](#)
[Function arguments - types](#)