

HI_ReportPar

%HI_ReportPar function

Function

The function **%HI_ReportPar** sets defined parameter of the displayer of Report type ([Control function](#)). For reports of *Crystal report* type only.

Declaration

```
%HI_ReportPar(  
    INT in refId,  
    TEXT in paramName,  
        in param1  
)
```

Parameters

refId	Reference to graphic object (reference variable).
paramName	Parameter name.
param1	Required parameter value.

Description

The function sets the the report parameter defined by the parameter *paramName* to the value defined by the parameter *param1*. The report is defined by the reference variable *refId*. The parameter *param1* must be an appropriate type (the type is given by the report configuration). Its value must be valid.

The value of the parameter is not immediately delivered to the report. The value is valid after calling the function [%HI_RefreshData](#). This feature allows to change several parameters at the same time.

Note

For detailed description of the report parameters see the topics [CrystalReport](#).



Related pages:

- [Graphic object manipulation functions](#)
- [Function arguments - types](#)