

Call-back Functions

D2000 KomAPI - interface call-back functions

The addresses of call-back functions are gained by calling the function [Init](#) in the [InitParams](#) structure. The call-back functions allow you to completely utilize the tools of the D2000 objects - [line](#), [station](#), [I/O tag](#) and they execute the auxiliary actions.

- [ActTime](#)
- [CreateList](#)
- [CreateThread](#)
- [ChangeLineMode](#)
- [DeleteEI](#)
- [DeleteList](#)
- [DeleteThread](#)
- [FindEI](#)
- [FindFirstEI](#)
- [FindFirstEIAndDelete](#)
- [FindNextEI](#)
- [FindPreviousEI](#)
- [FreeMem](#)
- [GetAppDir](#)
- [GetFastPoint](#)
- [GetMem](#)
- [GetNumber](#)
- [GetOemProtName](#)
- [GetPoint](#)
- [GetRdStateAndInstance](#)
- [GetStation](#)
- [InsertEI](#)
- [InsertEIPrio](#)
- [LnPerf_IncFramesIn](#)
- [LnPerf_IncFramesOut](#)
- [LnPerf_IncRetryErr](#)
- [LnPerf_IncRxBytes](#)
- [LnPerf_IncTxBytes](#)
- [MessageBox](#)
- [PointLastValidValue](#)
- [PointNewValue](#)
- [PointOldValue](#)
- [PointsApply](#)
- [ReadFromLine](#)
- [SetReceiveState](#)
- [SetStationStatus](#)
- [SetTransmitState](#)
- [StationsApply](#)
- [StPerf_CommActivity](#)
- [StPerf_IncFramesIn](#)
- [StPerf_IncFramesOut](#)
- [StPerf_IncRetryErr](#)
- [StPerf_TimeSynchro](#)
- [TimeFromItems](#)
- [TimeToItems](#)
- [TraceBufferASCII](#)
- [TraceBufferASCIIFile](#)
- [TraceBufferHex](#)
- [TraceBufferHexFile](#)
- [TraceComError](#)
- [TraceComErrorFile](#)
- [TraceComText](#)
- [TraceComTextFile](#)
- [WriteToLine](#)



Related pages:

[D2000 KomAPI](#)