HI_SetMetadata

%HI_GetMetadata, %HI_SetMetadata functions

Function

%HI_GetMetadata function gets back (according to the defined key) text value of metadata that are assigned to a graphic object.
%HI_SetMetadata function sets (according to the defined key) a text value of metadata that are assigned to a graphic object.

Declaration

```
TEXT %HI_GetMetadata(
   INT in _refId,
  TEXT in _key
 )

 BOOL  %HI_SetMetadata(
  INT in _refId,
  TEXT in _key,
  TEXT in _value,
  BOOL in _bOverWrite
 )
```

Parameters

_refId	Reference to graphic object (reference variable).
_key	Key which specified metadata.
_value	New value of metadata.
_bOverWrite	TRUE - either metadata are inserted (if they do not exist) or the value of existing metadata is updated. FALSE - either metadata are inserted (if metadata do not exist) or the existing value of metadata is kept.

Description

%HI_GetMetadata gets back (according to the set key) text value of metadata which is assigned to graphic object.
%HI_SetMetadata sets new metadata to the graphic object according to defined key.

Note 1

Configuration of metadata for graphic object.

%HI_SetMetadata function applies the change of metadata only on the running instance of picture.

Note 2

These functions are available also in %HIX_ version.

Related pages:

Graphic object manipulation functions
Function arguments - types