

GetDragDataIPS

%SetDragDataIPS, %GetDragDataIPS functions

Functions

Function **%SetDragDataIPS** sets a data container as a source of data for [Drag&Drop](#).

Function **%GetDragDataIPS** returns a data container, which is just transferred during Drag&Drop. If the function [%IsDragData\(0, _CF_IPS\)](#) does not return @TRUE, the return value of this function is undefined.

Declaration

```
%SetDragDataIPS(  
    INT in refId,  
    INT in cntData  
)
```

```
INT %GetDragDataIPS(  
    INT in refId  
)
```

Parameters

refId	It always requires 0.
cntData	Data container.

Return value

INT - returns a data container which is moved during Drag&Drop.



Related pages:

- [Graphic object manipulation functions](#)
- [Function arguments - types](#)