

HI_SetModeMove

%HI_SetModeMove function

Function

The function sets Picture to the "MOVE" mode from the script. Picture movement is possible with the "PACKY" mode. When applying this function, the picture cannot be controlled by [popup menu](#).

Declaration

```
%HI_SetModeMove ( )
```

Parameters

No parameters.

Note

This function is available also in [%HIX_version](#).

**Related pages:**

[Active picture manipulation functions](#)
[Picture local variables](#)
[Function arguments - type](#)