

HI_SetPictureDefaultButton

%HI_SetPictureDefaultButton function

Function

The **%HI_SetPictureDefaultButton** function sets a particular button on the table as "default".

Declaration

```
%HI_SetPictureDefaultButton(  
    INT in refId  
)
```

Parameters

refId	Reference to the graphic object of Button type (reference variable).
--------------	--

Description

The function sets a particular button on the table as "default" - i.e. the button will be activated (ENTRY OnClick is called) when clicking on ENTER key.



Related pages:

[Active picture manipulation functions](#)
[Function arguments - types](#)