Edit the Time Channel Data

Edit the time channel data

When browsing the representation of the time channel data flow, it is possible to carry out the following operations:

- Add / Delete day types
- Edit displayed calendar
 Change used calendar
- Edit the time channel data

To edit time channels click button that will be available only if user has the access rights to edit object of time channel. The dialog box is enhanced with the edit buttons after clicking the button.

CK01		— ———————————————————————————————————
Graph		
Description: Prvý casový kanál		
50 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	<mark>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>></mark>	12:00 AM 3/9/2010 12:00 AM 3/10/2010
Time interval: 3/7/2010 - 3	3/10/2010 — 🕂 1	<>
Day's types	Calendar - Aktual Display data	
Day types Pracovny Sobota Nedela Sviatok Dovolenka Leto_Zima Zima_Leto Den_Pred_VD Den_Po_VD	Year: 2010 Time Value Day Type March 1 2 3 4 5 6 7 1 2 3 4 5 6 7 07:00:00 8 Pracovny 8 9 10 11 12 13 14 09:00:00 7 Pracovny 15 16 17 18 19 20 21 11:00:00 4 Pracovny 22 23 24 25 26 27 28 12:00:00 3 Pracovny 13:00:00 2 Pracovny 13:00:00 2 Pracovny 14:00:00 1 Pracovny 15:00:00 0 Pracovny 15:00:00 0 Pracovny 15:00:00 0 Pracovny 15:00:00 0 Pracovny 00:00:00 55 Sobota	
Add Delete	Undo Save Change calendar Add Edit I	Delete

To add and delete day types

There are two buttons:

- Add clicking the button opens the dialog box to enter a name of new "Day type" object. The object is added to the list after entering.
- Delete it deletes and discards selected object from the list. If the button is not available, the selected object may not be deleted.

Edit displayed calendar

You can change types of days in displayed calendar as follows:

- 1. Select required day type in the list of day types.
- 2. Click the day you want to edit.

There are two buttons:

- Undo cancel all changes performed in the displayed calendar
- Save save all changes to the configuration database

The buttons will be available only if you carry out any change in edited calendar. Calendar may not be edited, if the buttons are not displayed.

Change used calendar

Clicking the Change calendar button opens the dialog box containing a list of available calendars. You may choose a new calendar from the list.

Edit the time channel data

There are three buttons:

- Add clicking the button opens the dialog box to add a new item of the time channel data. The object is added to the list after entering.
- Edit edit selected data item of the time channel.
- Delete delete selected item of the time channel.

and button to save changes of the time channel. The button will be displayed only if you edit any time channel item.

Clicking button terminates editing. Checking presence of any unsaved changes in the calendar and time channel is performed when you terminate editing. Detection of any changes opens the dialog box intended to save them.

(i) Related pages: Time channels