

# Requirement for archive object

[DDE reference](#) enables to get the status of object value:

= D\_2000|ARCH\_VALUE!blname\_N

**D\_2000** - DDE Server name (required)

**ARCH\_VALUE** - requirement for value of archive object

**blname\_N** is a string consisting of:

- **blname** - logic name of archive block (COM\_ID)
- **N** – consecutive number of archive value in archive block

The example of DDE reference is - [here](#).



## Related pages:

[Archive values](#)

[Requirement for particular archive value](#)