# Assign the Object to Logical Groups at its Configuration

Assigning the object to logical groups at its configuration

An object may be assigned to logical groups during its configuration (the D2000 CNF process) through the tab **Groups**.

The tab contents is formed by the tree structure of all logical groups defined in the application. The symbol in front of the name of each group shows if a configured object is or is not a member of the particular group. It may be changed by left-clicking a particular symbol.

☑	Includes the object in the selected group.
☐	Excludes the object from the selected group.

After the object is saved, the D2000 system performs the changes you made.