

HI_GetUserObjName

%HI_GetUserObjName function

Function

The function returns the name of the logged on user in the process [D2000 HI](#).

Declaration

```
TEXT %HI_GetUserObjName( )
```

Parameters

None.

Note

If no user is logged on, the function return a null string.

**Related pages:**

[Active picture manipulation functions](#)
[Function arguments - types](#)