

HI_GetPictureScrollY

%HI_GetPictureScrollY function

Function Function %HI_GetPictureScrollY gets back the value of the upper left point of zooming scheme on axis Y

Declaration

```
%HI_GetPictureScrollY()
```

Parameters No parameters.

Note 1 Function %HI_GetPictureScroll after calling %HI_SetPictureScroll gets back rounded value of the setting.

Note 2 This function is available also in [%HIX_ version](#).



Related pages:

[Active picture manipulation functions](#)
[Function arguments - types](#)