

# \_ERR\_NR\_TRANS\_EX - List of existing errors

The following table contains the list of existing errors returned by the local variable [\\_ERR\\_NR\\_TRANS\\_EX](#).

Internal name	Value	Description
<b>Error codes during work with system objects</b>		
OK	0	OK.
OBJECT_ALREADY_EXISTS	1	The object already exists.
OBJECT_NOT_FOUND	2	The object does not exist.
INVALID_ACCESS	3	Insufficient access rights.
SHARED_ACCESS_ERROR	4	Access error when trying to edit (object is being edited by other users).
OBJECT_NOT_OPENED	5	The object is not open.
OBJECT_IS_USED	6	The object is used (when trying to delete it).
INVALID_NAME	7	Invalid object name.
FATAL_ERROR	8	Fatal error.
OBJECT_IS_READ_ONLY	9	The object is read-only (when trying to edit or delete it).
OBJECT_HAS_CHILDREN	10	The object has children (when trying to delete it).
SAVE_REFERENCES_ERROR	11	Incorrect object references.
LICENCE_LIMIT_OVERRUN	46	License limit overrun (when trying to create a new object).
<b>Error codes for an output control</b>		
MANUAL_CTRL_DISABLED	12	Manual control disabled (when trying to set a value manually).
BAD_COMMAND	13	Bad command.
COMMAND_NOT_ACCEPTED	14	Illegal command.
PROCESS_NOT_RUNNING	15	The process for the command execution is not running.
<b>Error codes for configuration of the <a href="#">topology</a></b>		
CREATE_NEW_ERROR	16	Error during the creation of a new object of <a href="#">Topology</a> type.
BAD_PARENT	17	The object has another parent.
NAME_ALREADY_EXISTS	18	Object with the given name already exists - it is of another type.
BAD_CONNECT	19	Inappropriate control object for the topological node of <a href="#">Terminal</a> type.
<b>Error codes for the user's logins</b>		
USER_INVALID_ACCESS	20	Invalid access rights.
LOGON_WRONG_PASSWORD	21	Incorrect password. (version <= 12.2.65)
LOGON_NAME_ERROR	22	Incorrect login name. (version <= 12.2.65)

PASSWORD_EXPIR_TIME	23	Password validity has expired.
USER_IS_DISABLED	24	User login is disabled.
USER_EXPIR_TIME	25	The validity of the user's account has expired.
LOGON_NAME_PASSWORD_ERROR	54	Incorrect name or password. (version >= 12.2.67)
<b>Error codes for a database backup</b>		
DATABASE_NOT_VALID	26	Database not valid.
BACKUP_FAILED	27	Backup failed.
OTHER_ERROR	28	Other error.
PATH_NOT_COMPLETE	29	Path not complete.
<b>Error codes for access to the database ( <a href="#">D2000 Archiv</a>, <a href="#">D2000 DBManager</a>, <a href="#">D2000 Server</a> )</b>		
ODBC_ERROR	34	ODBC error.
<b>Error codes for connection to a processes</b>		
INVALID_VERSION	30	Incorrect version.
PROCESS_RUN_DISABLED	31	Cannot start the process.
PROCESS_LICENCE_DISABLED	32	Cannot start the process - insufficient license.
PROCESS_TCPIP_DENIED	33	Cannot start the process - IP address is denied.
<b>Error codes of the <a href="#">D2000 DBManager</a> process</b>		
PAGE_ERROR	35	Page error (in case of page access to the database).
EDIT_DISABLED	36	Editing disabled (when trying to write to a read-only table).
DBM_SEQUENCE_ERROR	37	<b>DBManager</b> sequence error (invalid object identifier, non-existing transaction, ...)
DATABASE_OPEN_ERROR	38	Open database error.
BAD_CONDITION	39	Bad conditions.
TOO_MANY_ROWS_IN_SELECT	48	Too many rows in selection (more than specified by the parameter <a href="#">Maximum returned rows</a> in the configuration of the object of <a href="#">Database</a> type).
DBM_CONNECTION_BROKEN_ERROR	49	Connection with the database has been interrupted.
DBM_MAX_CONNECTIONS	50	The maximum number of connections to the database has been reached (the parameter <a href="#">Maximum connections</a> in the configuration of the object of <a href="#">Database</a> type), a new connection has not been created.
STRUCT_CHANGE	51	Change of object of <a href="#">Structure definition</a> type in runtime (rows loaded from the database do not correspond to the changed object of <a href="#">Structure definition</a> type and are not to be sent to the <a href="#">D2000 Server</a> process).
DBM_DATABASE_OFF	52	Access denied: the object of <a href="#">Database</a> type is set to OFF (the parameter <a href="#">Off</a> in the configuration of the object)
<b>Error codes of the <a href="#">D2000 Archiv</a> process</b>		
LOAD_TREZOR_ERROR	40	Error in loading depository database.
CREATE_WRT_FILE_ERROR	41	Create a WRT file error when importing the Sybase depository database.
OPEN_TREZOR_ERROR	42	Error in opening depository database.
CREATE_STATISTICS_ERROR	43	Error in creating statistics file for the archive.

Error codes of Tell commands for the <b>D2000 KOM</b> process		
DUPLICATE_ADDRESS_ERROR	44	Duplicate address (when changing the address of I/O tag by using the Tell command <a href="#">SETPTADDR</a> )
POINT_NOT_FOUND_ERROR	45	I/O tag not found (for Tell command <a href="#">SETPTADDR</a> ).
Error codes of the <b>D2000 Application Manager</b> process		
INVALID_DB_PASSWORD	47	Invalid password for access to the configuration database.

Note: the error codes returned by the **D2000 DBManager** process when calling the [%GetLastExtErrorCode](#) function are described [here](#).