

CNT_GETNR

CNT_GETNR action

Declaration

```
CNT_GETNR _hContainer, _nrItems
```

Parameters

_hContainer	in	Identifier of <i>Int</i> type - data container.
_nrItems	out	Number of values in the container.

Description

The action returns the number of values in a specified [data container](#) and returns the number to the *_nrItems* parameter.

Example

[Work with data container \(actions CNT_...\)](#).



Related pages:

[Script actions](#)