

Values (User Variables)

Values of user variables

Object of **User variable** type may get various values in D2000 system. Values for individual types are listed in the following table.

- [Bo - Boolean](#)
- Int - Integer
- Re - Real
- TmA - Absolute time
- TmR - Time interval
- Txt - Text

User variables of *Bo-Boolean (logical)* type

Object value	Meaning
D_False	*the value FALSE
D_True	*the value TRUE
D_Oscillate	Oscillating value (TRUE <-> FALSE).



Related pages:

[User variables](#)

[User variables - configuration dialog box](#)