

Control the Text Inputs (Ttxtl) (D2000/Work with D2000 HI /Monitoring and Controlling of D2000 System Objects/Old Control Windows)

Controlling text inputs (Ttxtl)

!!! OLD CONTROL WINDOWS !!!

Clicking a graphic object with an I/O Tag of Text Input type connected to control (the user has insufficient access rights) opens the following control window.

1	Object name.
2	Object description.
3	Current value of the object.
4	Time when the objects has got the current value.
5	Flags (attributes) of the object value. There are displayed the names of flags, value of which is TRUE.
6	Acknowledge the object value (text).
7	Part of control window intended to set a default value .

Default value of text inputs (Ttxtl)

Checking the **Use default value** checkbox enables to use a default value. Control window is enhanced with control buttons that allows to set a default value. I/O Tag value can be replaced with a value of another object (so-called control object) or it can be set manually by operator of process [D2000 HI](#) in the control window.

1	Input edit box to enter a default value (text) of the object.
2	Set flags (attributes) of the object default value.
3	Depending on the Execute button, the SET button performs two possible functions: <ol style="list-style-type: none">1. The Execute button is not placed in the window. Clicking the Set button will set the defined default value along with value flags (attributes).2. The Execute button is placed in the window. Clicking the Set button only "prepares" the defined default value along with value flags (attributes) to set.
4	This button is placed in window if the Acknowledge option has been checked during the link configuration of the graphic object in the process D2000 GrEditor . Clicking the Execute button will set the defined value (or default value) together with value flags (attributes) that have been "prepared" to set by clicking the Set button.
5	Switch default value mode into automatic mode. Default value in this mode copies a value of control object.
6	Current value and state of control object value.
7	Cancel the validity of default value.
8	Insert the controlled object into current page of opened Browser. If Browser is not opened, clicking on this button will open it and the controlled object will be inserted into its first page.
9	Close the control window.