

Requirement for archive object

[DDE reference](#) enables to get the status of object value:

= D_2000|ARCH_VALUE!blname_N

D_2000 - DDE Server name (required)

ARCH_VALUE - requirement for value of archive object

blname_N is a string consisting of:

- **blname** - logic name of archive block (COM_ID)
- **N** – consecutive number of archive value in archive block

The example of DDE reference is - [here](#).



Related pages:

[Archive values](#)

[Requirement for particular archive value](#)