

DDE Server - starting

DDE Server can be started in two ways.

Clicking on DDE Server icon

1. Click on **Start** button (bottom left corner of desktop) -> **Programs** and choose **D2000 V10.00** directory.
2. Then double click on the icon **D2000 DDE Server**. DDE Server starts.

Starting from command line

1. Click on **Start** button on the bottom left corner of desktop.
2. Choose **Run...**
3. Enter the path, .exe name of DDE Server (d2dde.exe) and [start parameters](#).
4. Press **OK** and DDE Server starts.



Related pages:

[Start parameters of DDE Server](#)
[Logon to DDE Server](#)
[Process DDE Server - Close](#)