

# Logoff (Access to the HI Process)

## HI process - Logoff

You can logoff after finishing your work in process [D2000 HI](#).

**To log off from the HI process use the following way:**

- Select the **Logoff** item from **System** menu

To avoid access right violation of the operator who is not logged off and isn't performing any interactions to process [D2000 HI](#), there is implemented the automatic user logoff in HI process. If the user is not operating with HI process during given timeout, he is automatically logged off. System administrator defines a timeout period after which user will be logged off. Timeout period is defined specially for each user during his/her configuration by means of the process [D2000 CNF](#).



### Related pages:

[Access to the HI process](#)