

TestStatus

TestStatus function

Function

The function returns TRUE, if status of object is the same as particular one which is defined by parameter **Stat**. If not, it returns FALSE.

Status name	Meaning
Normal	Valid value
Undefined	Undefined value
Out of Range	Out of range
Error	Error
Div by Zero	Dividing by zero

Declaration

```
= TestStatus (DDEreference, Stat)
```

Parameters

DDEreference	DDE reference in the format D_2000 STATUS!objname or D_2000 ARCH_STATUS!blname .
Stat	Status: InLimit, VLL, LL, HL, VHL, Transient, Default, Weak, Weak CMD, Weak ANS, Limits problem.

Example

```
= TestStatus (D_2000 | STATUS!U.Kx_O2_Ref_Plyn, Normal)
```



Related pages:

[Implemented function](#)