

HI_CloseRow

%HI_CloseRow function

Function The function terminates updating of the row values of the object of Structured variable ([Control function](#)).

Declaration

```
INT %HI_CloseRow(  
    HBJ in refToStruct,  
    INT in index  
)
```

Parameters

refToStruct	Reference to the object of Structured variable type.
index	Structured variable row.

Description The function terminates updating the values of the structured variable row defined by the parameter *index* . The structured variable is defined by the parameter *refToStruct* of HBJ type (for example: [SV.Structure\HBJ](#)). Value of the parameter *index* is not checked because of the size of the structured variable.

Example Termination of updating the values of the row 5 of the structured variable *SV.Structure*:

```
_retCode := %HI_CloseRow(SV.Structure\HBJ, 5)
```



Related pages:

- [Active picture manipulation functions](#)
- [Indexed local variables](#)
- [Function arguments - types](#)