

HI_GetVisible

%HI_GetVisible, %HI_SetVisible functions

Function	<p>The function %HI_SetVisible allows to hide/show the graphic object (Control function).</p> <p>The function %HI_GetVisible detects whether the graphic object is visible.</p>				
Declaration	<pre>%HI_SetVisible(INT in refId, BOOL in bVisible) BOOL %HI_GetVisible(INT in refId)</pre>				
Parameters	<table><tr><td>refId</td><td>Reference to graphic object (reference variable).</td></tr><tr><td>bVisible</td><td>@TRUE - show the graphic object. @FALSE - hide the graphic object.</td></tr></table>	refId	Reference to graphic object (reference variable).	bVisible	@TRUE - show the graphic object. @FALSE - hide the graphic object.
refId	Reference to graphic object (reference variable).				
bVisible	@TRUE - show the graphic object. @FALSE - hide the graphic object.				
Description	The function also allows to show / hide a tab of Windows control of Tab control type - the parameter <i>refId</i> determines the reference variable name of the tab.				
Note 1	This function is available also in %HIX_ version .				



Related pages:

- [Graphic object manipulation functions](#)
- [Function arguments - types](#)