

# HI\_SetModeMove

## %HI\_SetModeMove function

### Function

The function sets Picture to the "MOVE" mode from the script. Picture movement is possible with the "PACKY" mode. When applying this function, the picture cannot be controlled by [popup menu](#).

### Declaration

```
%HI_SetModeMove( )
```

### Parameters

No parameters.

### Note

This function is available also in [%HIX\\_ version](#).



### Related pages:

- [Active picture manipulation functions](#)
- [Picture local variables](#)
- [Function arguments - type](#)