

HI_SetEditEnable

%HI_SetEditEnable, %HI_GetEditEnable functions

Function

The function **%HI_SetEditEnable** enables/disables editing the text in the specified item of the display of **Browser** type ([control function](#)).

The function **%HI_GetEditEnable** detects whether editing the text in the specified item of the display of **Browser** type is possible or not.

Declaration

```
%HI_SetEditEnable(  
    INT in refId,  
    INT in row,  
    INT in col,  
    BOOL in bEnable  
)  
  
BOOL %HI_GetEditEnable(  
    INT in refId,  
    INT in row,  
    INT in col  
)
```

Parameters

refId	Reference to graphic object (reference variable).
row	Item row.
col	Item column.
bEnable	@TRUE - enable editing the item. @FALSE - disable editing the item.

Example

```
; change editing the item placed in 2nd row and 3rd column
```

```
BOOL _bEnable
```

```
_bEnable := %HI_GetEditEnable(_browser, 3, 2)
```

```
_bEnable := !_bEnable
```

```
%HI_SetEditEnable(_browser, 3, 2, _bEnable)
```



Related pages:

[Graphic object manipulation functions](#)
[Function arguments - types](#)