

HI_ReportPrint

%HI_ReportPrint function

Function

The function **%HI_ReportPrint** allows to print the display of the Report type, that is placed in the picture ([Control function](#)).

Declaration

```
%HI_ReportPrint(  
    INT in refId  
)
```

Parameters

refId	Reference to graphic object (reference variable).
--------------	---

Description

The function allows to print the display of **Report** type. The display is defined by the reference variable *refId*.

The printer, that prints the report, is given by the setting of the report interpreter. For example: the printer for a report of Excel type, is defined by the configuration of the MS Excel.



Related pages:

[Graphic object manipulation functions](#)
[Function arguments - types](#)