
## **Status Diagram**

## Status diagram of system alarms

The status diagram of system alarms shows all the possible states of Alarm object and changes of them. It is illustrated on the following figure.



Normal	Condition of finishing an alarm is met. If it is not defined then the condition of starting the alarm has disappeared.
Normal*	Change into the Unacknowledged state occurs if the alarm object is defined as an acknowledgement-required alarm in its configuration.
Alarm	Condition of starting an alarm is met.
Block	The alarm is blocked by operator.
Acknowl.	The alarm is acknowledged by operator.