

System Alarm States (D2000)

System alarm states

System alarms can occur in various states. Overview of all Alarm object states is shown in the following table.

Object state	Cause
Normal	No condition to start alarm has occurred.
Alarm	Condition to raise alarm has occurred.
Acknowledged	Alarm has been acknowledged by operator.
Blocked	Alarm is blocked by operator or the Blocked alarm parameter has been checked at the alarm configuration in process D2000 CNF .
Error	Object state cannot be evaluated.
Unacknowledged	Condition to finish the acknowledgement-required alarm had been met before its acknowledgement.
Unblocked	State occurs only if process D2000 Alarm is not running and operator unblocked given alarm in the Blocked state.



Related pages:

[Graphic alarm symbols](#)