

Server Event

Server Event, analogous to [Start up event](#), **is started automatically**:

- after starting its parent (process [D2000 Event Handler](#))
- after saving it while its parent (process **D2000 Event Handler**) is running
- after calling the [OPENEVENT](#) action

The automatic start is activation of the [script initialization part](#). After termination of this part, the event remains in the state Running and "waits" for incidents, that activate the handling procedure.

The incidents may be generated by:

- value change of the monitored object. Value monitoring is controlled by the action [ON CHANGE](#).
- [remote procedure call](#) of the event.



Related pages:

[Events](#)

[Start conditions](#)

[Events - configuration dialog box](#)