

# Users

D2000 system allows creating and defining parameters of a new user by means of object of **User** type. The process [D2000 CNF](#) allows to work with such objects. Using such an object allows to define user name, password, expiration time, access rights and actions which are enabled in the D2000 system.

**Note:** Starting with D2000 version 7.02.009 the object of **User** type has an integer value equal to number of user's logons to system (specifically logons to processes [D2000 HI](#), [D2000 GrEditor](#), [D2000 CNF](#), [D2000 Application Manager](#), [D2000 DDE Server](#), [D2000 System Console](#), [D2000 Tell](#), [D2000 Browser](#)).



## Related pages:

[Create a new user](#)

[Configuration of user parameters](#)

[User's access to D2000 system objects](#)

[User - Console](#)

[ReadOnly mode](#)