

The User - Console

User - Console

The user **Console** is a special virtual user assigned to particular operator console (process [D2000 HI](#)). Special user type is given by his/her logon name. This name comprises of the name of the process [D2000 HI](#), e.g. SELF.HIP, and the suffix **LOG**. Name of virtual user for the console SELF. HIP is then SELF.HIP.LOG. The sequence of characters ".HIP.LOG" in the name defines, that it is a user *Console*. (Name of a user, created in the process [D2000 CNF](#), may not include the sequence of characters mentioned before).

Special features of user Console

A object group and user's composition can be assigned to user *Console*. User *Console* is characterized by the following features:

- password definition is not allowed,
- performing special functions is not allowed,
- automatic logon to the console after starting the process [D2000 HI](#),
- if a composition is defined, it will be displayed immediately after starting the process [D2000 HI](#),
- user of the console defines the operator console access (process [D2000 HI](#)) to objects in the time, when no user is logged on (very important, e.g. for presentation of alarms also at the time, when no user is logged on). If a user logs on, the effective access rights to objects are given by the integration of the console access rights and the user's access rights.



Related pages:

[Users](#)