


Log On to Server


D2000 System Console - log on to server

To view the output of a server and control it, you must log on to the server. The logon dialog box is opened after right-mouse clicking the server name in the [list of redundant groups, servers and processes](#) and selecting the item **Connect** from the open [menu](#).

Login dialog in case of D2000 authentication:



Login dialog in case of NTLM authentication:



Login

Logon name.

Password

Logon password.

Domain

Windows domain.

When you type a correct name (input field **Login**) and password (input field **Password**) and click the button **OK**, there will be displayed [information on selected server](#) in the text console (4) of the [D2000 System Console window](#).



Related pages:

[D2000 System Console - controlling servers](#)