


# Send a Tell Command to Server

## D2000 System Console - sending a Tell command to server

Right-mouse clicking on the name of a server in the [list of redundant groups, servers and processes](#) and selecting the item **Command** from the open [menu](#) opens the following dialog box. It allows to send a Tell command to the server.



**Tell**

Command:

Description: Shows dynamic information on specified object

Parameter: object\_name | HOBJ:

Time sent:

Time answer:

Status:

Answer:

### Command

Selection of a Tell command.

### Description

Description of the parameter.

### Parameter

Definition of parameters of the Tell command.

The command is sent to the server after clicking the button **OK**. You can watch the overview of commands (list of received and sent commands, times, responses, ...) in the [text console](#) - the tab **Tell**.



#### Related pages:

[D2000 System Console - controlling servers](#)