

# StPerf\_IncFramesOut

---

## Declaration

```
void (_stdcall *StPerf_IncFramesOut)(HOBJ StID)
```

---

## Parameters

|      |             |
|------|-------------|
| StID | Station ID. |
|------|-------------|

---

## Description

The function increments the number of frames that were sent from the given [Station](#).



Related pages:

[D2000 KomAPI - call-back function](#)