

StPerf_IncFramesOut

Declaration

```
void (_stdcall *StPerf_IncFramesOut)(HOBJ StID)
```

Parameters

StID	Station ID.
------	--------------------------------

Description

The function increments the number of frames that were sent from the given [Station](#).



Related pages:

[D2000 KomAPI - call-back function](#)