

ExitProcWithLnPar

Declaration

```
void _stdcall ExitProcWithLnPar(LinePar *Ln)
```

Parameters

Ln	Pointer to LinePar .
----	--------------------------------------

Description

ExitProc (_ExitProcWithLnPar@4 in Stdcall convention) is called before stopping the [D2000 KOM](#) (stopping **D2000 KOM** by a user, stopping [D2000 Server](#)). The function handling should be as fast as possible. You should realize that D2000 KOM process could have been already stopped and the use of [c all-back function](#) may be incorrect.



Related pages:

[D2000 KomAPI - functions](#)