


Pictures (GrEditor Settings)

GrEditor settings - Pictures

The tab **Pictures** allows to set the parameters of grid. For more information on the grid, see the topic [Grid](#).



Description of the parameters included in the tab **Pictures** is listed in the following table.

| Parameter | Description |
|-------------|--------------------------------------------------------------|
| Horizontal | Sets a horizontal spacing between grid points. |
| Vertical | Sets a vertical spacing between grid points. |
| Show | Shows the grid. |
| Align | Enables to align the graphic objects to the grid. |
| Auto select | Automatically selects the graphic object after its creating. |



Related pages:

[Graphic Editor settings](#)